VXE Easyfit DN 10÷50





2-Way Ball Valve

D a alve	materials
BOOV	moteriois

PVC-U PVC-C

Ball seats material

PTFE

Seals materials

EPDM FKM

Accessories

Transparent protection plug with tag holder (LCE) Easytorque Kit (KETO1) End connections (Butt Weld.) in PE (CVDE)

d [mm]		16	20	25	32	40	50	63	
DN [mm]		10	15	20	25	32	40	50	
SIZE [inch]		3/8"	1/2"	3/4"	1"	1"1/4	1" 1/2	2"	Туре
100 DIN	PVC-U	•	•	•	•	•	•	•	VXEIV
ISO-DIN metric series plain female ends	PVC-C	•	•	•	•	•	•	•	VXEIC
piani remaie enas									
BSP series	PVC-U	•	•	•	•	•	•	•	VXEFV
threaded female ends	PVC-C	•	•	•	•	•	•	•	VXEFC
BS socket welding	PVC-U	n.a.	•	•	•	•	•	•	VXELV
ASTM series plain female ends	PVC-U	n.a.	•	•	•	•	•	•	VXEAV
	PVC-C	n.a.	•	•	•	•	•	•	VXEAC
NPT series	PVC-U	n.a.	•	•	•	•	•	•	VXENV
threaded female ends	PVC-C	n.a.	•	•	•	•	•	•	VXENC
JIS series	PVC-U	n.a.	•	•	•	•	•	•	VXEJV
plain female ends									
JIS series	PVC-U	n.a.	•	•	•	•	•	•	VXEGV
threaded female ends									
BW Long spigot male	PVC-U	n.a.	•	•	•	•	•	•	VXEBEV
ends for butt welding with PE100 SDR 11									
PN [bar]	PVC-U	16	16	16	16	16	16	16	
16 bar = 232 psi	PVC-C	16	16	16	16	16	16	16	
Kv100 [l/min]		80	200	385	770	1100	1750	3400	

Notes: n.a.= not available

Multifunctional handle and Easytorque Kit





Nuts tightening

Easytorque kit is the innovative tool designed by FIP for optimal tightening and adjustment of all threaded components of the Easyfit valves (carriers and nuts) applying a defined and repeatable torque.

The use of the Easytorque wrench is recommended to minimize mechanical stresses on thermoplastic threads, preventing fluid leakage, optimizing ball valve operation and minimizing the wear out of the elastomeric seals. The use of the Easyfit torque wrench as well as the multifunctional handle also avoids non specific tools causing union nut accidental damaging..





Ball Seat Carrier adiustment

Easyfit Labelling System

Easyfit Labelling System helps you to customize valves with company brands, serial or identifying numbers or service

information such as the function of the valve inside the plant, the conveyed fluid, but also specific information for after selling customer service, such as the customer's name.



or date and place of the installation. More details on www.fipnet.com/fip-labelling-system/

VXE Easyfit DN 65÷100





2-Way Ball Valve

Body materials

PVC-U PVC-C

Ball seats material

PTFE or PE

Seals materials

EPDM FKM

Accessories

Easyfit Actuation module (Power Quick Easyfit) Stem extension (PSE)

Transparent protection plug with tag holder (LCE) Customisation set (LSE)

End connections (Butt Weld.) in PE (CVDE)

		75	22	440	
d [mm]		75	90	110	
DN [mm]		65	80	100	
SIZE [inch]		2" 1/2	3"	4"	Type
ISO-DIN metric series	PVC-U	•	•	•	VXEIV
plain female ends	PVC-C	•	•	•	VXEIC
BSP series	PVC-U	•	•	•	VXEFV
threaded female ends	PVC-C	•	•	•	VXEFC
BS socket welding	PVC-U	•	•	•	VXELV
ASTM series	PVC-U	•	•	•	VXEAV
plain female ends	PVC-C	•	•	•	VXEAC
NPT series	PVC-U	•	•	•	VXENV
threaded female ends	PVC-C	•	•	•	VXENC
JIS series	PVC-U	•	•	•	VXEJV
plain female ends					
JIS series	PVC-U	•	•	•	VXGEV
threaded female ends					
BW Long spigot male	PVC-U	•	•	•	VXEBEV
ends for butt welding with PE100 SDR 11			·	·	
PN [bar]	PVC-U	16	16	16	
16 bar = 232 psi	PVC-C	16	16	16	
Kv100 [l/min]		5000	7000	9400	

Easyfit Quick-release Multifunctional Handle

Thanks to the innovative Easyfit System,

the handle can be easily released from



the hub to carry out the union nuts rotation during valve installation and the ball seat carrier adjustment. The handle can be turned into a wrench key for tightening or loosening the union nuts simply removing, flipping and engaging the insert housed inside it in the appropriate seat. The tool so composed is extremely rugged and light at the same time offering an excellent eraonomic arip. The insert design engages perfectly on the external profile of the union nuts with a secure grip allowing to exercise a high torque without damaging the nuts in any way. The handle can also be used as a tool for disassembly, assembly or adjustment of the support of the ball seat carrier. For this function, once removed the handle from the hub enter the two upper protrusions into the appropriate slots of the

seat carrier to screw or unscrew it.



Nuts tightening



Ball Seat Carrier adjustment

Easyfit Labelling System

Easyfit Labelling System helps you to customize valves with company brands, serial or identifying numbers

or service information such as the function of the valve inside the plant, the conveyed fluid, but also specific information for after selling

customer service, such as the customer's name, or date and place of the installation.

More details on www.fipnet.com/fip-labelling-system/

Pressure /Temperature rating for water and harmless fluids to which the material is resistant. In the other cases a reduction of the rated PN is required.

		0	20	40	60	80	100	°C	
	bar								
	16								
	14			PVC-U					
e e	12								
working pressure	10								
	8								
vork	6								
	4								
	2								
	0								
	working temperature								





